

INSTALLATION INSTRUCTIONS

Parts Included

- Faucet body with spout • 2 Handles • 2 Adapters • 2 Compression nuts with washers
- 2 Locknuts • 2 Washers • Sidespray assembly • Sidespray hose •

Tools Needed

- Adjustable Wrench • Slip Joint Pliers • Pipe Putty or Teflon Pipe Tape •



1. Shut off hot and cold water supply under sink. Plug sink drain with cloth to avoid losing small parts.
2. Thread adapters into faucet body using teflon tape.
3. Mount faucet body to sink using teflon tape and tighten from below.
4. Install sidespray holder. Thread hose on to sidespray. Feed sidespray hose through sidespray holder and attach hose to faucet connection.
5. Attach handles to faucet body.
6. Turn on your new faucet for the first time. Allow both hot and cold water to run for one minute.

NOTE:

1. Use teflon tape on all threaded connections.
2. Flush line before faucet installation to remove debris
3. Take care not to keep plumber's putty on any finish to corrode finish of faucet surface.
4. Take care not to damage the finish with tools during installation.

Care and Maintenance:

1. To clean, simply wipe with a clean soft cloth.
2. Please do not use sponge. Also, do not use abrasive cleansers or solvents to clean the faucet.