SONNEMAN[®]

Assembly Instructions for: item 3613 Milano - Pendant 3 light

Important: Always unplug the power cord before installing or replacing bulb and before cleaning or other maintenance.

This light should be installed by a licensed electrician

Assembly & Installation Instructions

- 1. Shut off power to outlet box.
- 2. Place Mounting Plate over outlet box and secure it with two screws.
- 3. Screw or unscrew stems to adjust desire height.
- 4. Make appropriate electrical connections using wire nuts.

Connect the black fixture wire to black supply wire. Connect white fixture wire to white supply wire.

If there is no green ground wire from the outlet box,

connect the fixture ground wire to the mounting plate with

the green screw provided. Place connections in outlet box.

- 5. Place Backplate over Mounting Plate and screw it with two nuts.
- 6. Place one Plastic Washer over Socket.
- 7. Place Glass Shade over Socket
- 8. Place second plastic washer on glass shade
- 9. Secure Glass Shade with Socket Ring.
- 10. Install A19 or G25 bulbs (not included)

